


Модуль частотного ввода MFI-041



Контакт	X1.1	X1.2	X1.3	X1.4		Контакт	X2.1	X2.2	X2.3	X2.4	
Цепь	FIN11	FIN12	FIN21	FIN22		Цепь	FIN31	FIN32	FIN41	FIN42	
Контакт	X5.1	X5.2	X5.3	X5.4	X5.5	Контакт	X6.1	X6.2	X6.3	X6.4	X6.5
Цепь	AD 1	AD 2	AD 3	AD 4	GND	Цепь	AD 6	AD 5	GND	TERM1	TERM2
Контакт	X3.1	X3.2	X3.3	X3.4	X3.5	Контакт					
Цепь	0V	CAN-H	CAN-L	CAN-GND	+24V	Цепь					